

BMW X5 - 2007 - 2018 (inc. 2014 facelift)

5-Seater

Our ref: H0447

PACKAGING REQUIREMENTS.



CARGO LINER

- 2 x 430mm - 20mm wide self-adhesive loop fastener
- 10 x tabs self-adhesive loop fastener



LIFTGATE COVER

- 20 x tabs self-adhesive loop fastener



DROP-DOWN LIFTGATE COVER

- 19 x tabs self-adhesive loop fastener



STEP 1. PREPERATIONS

- Remove the retractable cargo cover. This can be replaced carefully once the cargo liner has been installed.
- Unlock the 2nd row seats and fold down flat.



VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fastener to attach the cover to the plastic trim it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many detailing products. It is **highly likely there will be a build-up of silicone**. Before applying any self-adhesive fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone). We recommend Intensive Tar Remover made by AutoGlym. Wipe off thoroughly **any residue with a separate clean dry cloth**.

NOTE: the adhesive takes 24hrs to reach full adhesion – do not touch during.



STEP 2. INSTALLING BASE

- **Photo A.** Starting at the liftgate end install the pocket over the drop-down liftgate.
- Position the base of the liner snugly into place.
- **Photo B.** Push the foam-filled tabs into the void between the floor and the upper parts of the rear seats. It is a bit of a squeeze! (This photo is not specific to your car)
- Carefully re-lock the 2nd row seats.



STEP 3. INSTALLING THE FRONT

- **Photo C.** Pass the fastener straps around the headrest posts and fasten close to the liner.
- **Photo D.** Pass the elastic strap around the middle headrest and fasten close to the liner.

REAR PLUS

Please note on REAR PLUS version liners – you will need to unfasten the headrest straps before you attempt to fold your 2nd row seats flat!



STEP 4. INSTALLING THE SIDES

- Position the side panels snugly into place.
- Use the self-adhesive loop fastener to attach the sides to the plastic panels.
- **Image E.** Attach the two hook fastener tabs to the plastic moldings that take the retractable cargo cover, using the self-adhesive loop fastener pads – trim excess.



OPTIONAL EXTRAS

Please note: the following photos are not specific to your vehicle

STEP 5B. LIFTGATE COVER

- Line up the liftgate cover with the liftgate and clean the areas where the self-adhesive fastener tabs will be stuck. **(Image 1)**
- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



STEP 5C. BUMPER FLAP

- Install Cargo liner
- Attach the Bumper Flap to the loop fastener strip located at the base of the cargo liner. **(Image 2)**
- The Bumper Flap is one standard length for all models. Trim the length to suit your requirements. Ensure you do not cut through the stitching.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the liftgate.

