

Nissan Pathfinder 2005-2013 (3rd row seats folded into floor)

OUR PATT REF: H0449-R3FLD

Our packing requirements

- ☐ Cargo liner
- ☐ Min 32 self-adhesive loop fastener pads
- ☐ 2 of self-adhesive loop fastener + webbing straps (our ref: 119)
- ☐ LIFTGATE Cover
- ☐ Min 21 self-adhesive loop fastener pads



REF:119



IMPORTANT PREPARATION

To ensure a good bond: when using the self-adhesive hook & loop fasteners to attach the Bootliner to the plastic (NOT the carpet), it is most important to remove the silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many detailing products. It is highly likely there will be a build-up of silicone.

Before applying any self-adhesive fasteners pads, the surface **MUST** be thoroughly cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone) We recommend Intensive Tar Remover made by AutoGlym. Wipe off thoroughly any residue with a separate clean dry cloth.

NOTE: The adhesive takes 24hrs to reach full adhesion – do not disturb during this time. In cold weather we advise you to fit the liner in a warm environment (i.e. run the car till the interior is warm)



PHOTO A



PHOTO B

- Remove the retractable cargo cover and left side storage net: **PHOTO A**
- Using the 2 of self-adhesive loop fastener + webbing straps (our ref: 119) to fix the 3rd row seat belts as indicated in **PHOTO B**, so that they lie flush to the side panel. (Remove paper backing and fix over seat belt.)

FITTING

- **BASE:** Starting at the liftgate end, position base of the liner snugly into place. Attach the two ties to the corresponding luggage hooks. Use the self-adhesive loop fasteners to attach the liner to the metal liftgate plate. To the front, the hook fasteners on the liner attach directly to the carpet. (Note: the base does not span the void behind the rear seats.)
- **FRONT PANEL:** Pass the hook & loop fastener straps around the headrest posts and fasten close to the liner. The hook fasteners on the back side of the liner attach directly to the carpet.
- **SIDE PANELS:** Position the side panels snugly into place. Use the self-adhesive loop fasteners to attach the sides to the plastic panels.
- *Please note on REAR PLUS version liners – you will need to unfasten the headrest straps before you attempt to fold your 2nd row seats flat!*



Optional extra – Rear Door Cover

Use the self-adhesive loop fasteners to attach the cover to the plastic panel.