

Mini Hardtop 2 Door - 2007 - 2014

our ref: H0459

PACKAGING REQUIREMENTS:

CARGO LINER

- 8 x tabs self-adhesive loop fastener

LIFTGATE COVER NOT AVAILABLE



Rear Plus cargo Liner



VERY IMPORTANT PREPARATION



To ensure the self-adhesive hook & loop fastener stick to the plastic trim, you **MUST CLEAN** all grime from the plastic and **REMOVE** all **SILICONE** applied during manufacture and detailing.

To do this please:

1. Use a silicone remover, such as AutoGlym Intensive Tar Remover, and apply generously to the surface you want to adhere to.
2. Using a separate clean, dry cloth, thoroughly dry the surface until the cloth starts to drag. Attach one self-adhesive fastener tab to see if it sticks. (Repeat steps 1 and 2 if necessary.) Extra tabs have been provided.
3. Attach the self-adhesive fasteners and let them fully adhere over the next 24 hours for the best bond.

**The self-adhesive fasteners cannot be used once they have been in contact with silicone. Replacement kits are available on our website.*



Please note: not all of the photographs are specific to your vehicle

STEP 1. PREPARATIONS

- Remove the load cover. It may be replaced later.

STEP 2. INSTALLING THE BASE

- Place the cargo liner into the cargo area with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges. The hook fasteners on the back side attach directly to the carpet. (Image A)



STEP 3. INSTALLING THE FRONT

- PLUS / SPLIT VERSION ONLY** - Fasten the hook & loop fasteners between the side panels and the seat panel. (Image B)
- Starting with the middle headrest, fasten the hook & loop fastener straps around both headrest posts. (Image C). Make sure to hold the front part of the base in position to avoid pulling the cargo liner too far up. Repeat the procedure with the left and right headrests.

REAR PLUS VERSIONS

You **MUST** unfasten the hook & loop fasteners and the headrest straps before you recline the upper part of the rear seats. (Please refer to **REAR PLUS / SPLIT** options on website to see detailed photo.)



STEP 4. INSTALLING THE SIDES

- Attach the hook fastener on the top edge and liftgate end of the cargo liner sides directly onto the carpeted sides of the cargo area. (Image D)



STEP 5. INSTALLING THE BACK

- Stick the 8 x self-adhesive loop fastener tabs to the plastic panel located at the liftgate end of the side of the cargo area, aligned with the hook fastener on the back of the cargo liner. (Image E)



OPTIONAL EXTRAS

Please note: the following photos are not specific to your vehicle.

STEP 5A. BUMPER FLAP

- Install the cargo liner
- Attach the Bumper Flap to the loop fastener strip located at the base of the cargo liner. (Image 1)
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the liftgate.



STEP 5B. CARGO LINER EXTENSION

The cargo liner extension provides superior protection for the rear seats when purchased with a REAR PLUS option. (Image 2)

- The cargo liner Extension is designed to attach to a Rear Plus version liner.
- It provides additional protection for the back of the front seats and the extended cargo area floor area when the rear seats are folded flat.
- The max. width is 148cm (Image 6)
- It offers no protection to the rear doors



The Bumper Flap 5A and Cargo Liner Extension 5B cannot be added at a later date

STEP 5C. FREQUENT USE INSTALLATION KIT

- If you frequently remove/install your cargo liner from/to your vehicle, please note that the carpet will “fluff” up – we offer an alternative Frequent Use Installation Kit (Image 3+4)

The Frequent Use Installation Kit is available to from our on-line Store – simply add it to your order from the Store. The kit can also be ordered at a later date.

