

AUDI Q5 2009 - 2017

Our ref: Ho460

PLEASE NOTE:

Rear seats slid as far back to the liftgate.

Rear seat uppers locked in the most upright rake.

Packing requirements:

- ☐ CARGO LINER
Minimum of 1 self-adhesive loop fastener tabs
- ☐ LIFTGATE COVER
Minimum of 20 self-adhesive loop fastener tabs



PREPARATION

- Remove the retractable cargo cover
- Photo A:** slide the net down so it sits flush with floor

INSTALLING

BASE PANEL

- Position the base of the liner snugly into place.
- The fastener Tabs on the base panel attach directly to the carpet.

FRONT PANEL

- Pass the hook & loop fastener straps around the headrest posts and fasten close to the liner.

SIDE PANELS

- Position the side panels snugly into place.
The fasteners attach directly to the carpet.



OPTIONAL EXTRAS

Rear Plus version liners – you will need to unfasten the headrest straps before you attempt to fold your 2nd row seats flat!

Liftgate Cover: Use the self-adhesive loop velcro supplied to attach the sides to the plastic panels.

LIFTGATE COVER IMPORTANT PREPARATION

To ensure a good bond: when using the self-adhesive fastener to attach the cargo liner to the plastic (NOT the carpet), it is most important to remove the silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many detailing products. It is highly likely there will be a build-up of silicone.

Before applying any self-adhesive fastener pads, the surface **MUST** be thoroughly cleaned using a silicone remover. (The fasteners cannot be used once they have been in contact with silicone) We recommend Intensive Tar Remover made by AutoGlym.

Wipe off thoroughly any residue with a separate clean dry cloth.

NOTE: The adhesive takes 24hrs to reach full adhesion – do not disturb during this time. In cold weather we advise you fit the liner in a warm environment (i.e. run the car till the interior is warm)