

VW TOUAREG 2011 - 2017

Our ref H0516

PACKING REQUIREMENTS



CARGO LINER

Minimum of 2 self-adhesive loop fastener tabs



LIFTGATE COVER

Minimum of 19 self-adhesive loop fastener tabs



Photo of REAR PLUS with SPLIT seat version



PREPARATION

- Remove the cargo cover. It can be replaced later.
- **Photo A.** Ensure the 2nd-row seats are positioned most upright and slid as far back to the liftgate.

INSTALLATION

BASE

- Place the liner into the car and install the base snugly into place. Position the front of the base to the rear seat end first and work backwards. The hook fasteners on the back side of the base panel attach directly to the carpet.

FRONT (Has the Hatchbag label)

- Pass the hook & loop fastener straps around each corresponding headrest posts and fasten close back upon themselves.
- The hook fasteners on the back side of the front panel attach directly to the carpet.

REAR PLUS VERSIONS - YOU MUST UNFASTEN THE HOOK & LOOP FASTENERS AND THE HEADREST STRAPS BEFORE YOU RECLINE THE UPPER PARTS OF THE REAR SEATS





Photo B



Photo C

SIDES

Carefully position the side panels snugly into place.

Photo B:

The hook fasteners on the back side of the base panel attach directly to the carpet.

LEFT SIDE POCKET / RECESS

Photo C:

Position the top edge of the liner side panel first, then install the recess section. Fold the pocket flap over and use the self-adhesive tabs to attach it to the inner face of the plastic panel.



Photo D

BOTH SIDES

Photo D:

Place the liftgate edges under the rubber seal.

OPTIONAL EXTRAS

LIFTGATE COVER

Use the self-adhesive loop fastener tabs to attach the cover to only the plastic trim area.



liftgate cover (generic photograph)

IMPORTANT PREPARATION for LIFTGATE COVER ONLY

To ensure a good bond, when using the self-adhesive hook & loop fasteners to attach the Cargo liner to the plastic / metal trim (**Not** the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many detailing products. It is **highly likely there will be a build-up of silicone**. Before applying any fasteners pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The hook & loop fasteners cannot be used once it has been in contact with silicone). We recommend Intensive Tar Remover made by AutoGlym. Wipe off thoroughly **any residue with a separate clean dry cloth**.

Unfortunately, we are unable to supply this product, as it cannot be transported via our postal carrier.

NOTE: the adhesive takes 24hrs to reach full adhesion – do not disturb during.

FREQUENT USE INSTALLATION KIT

If you frequently remove/install your Cargo liner from/to your vehicle, please note that the carpet will “fluff” up. We offer an alternative Frequent Use Installation Kit.

The Frequent Use Kit is available to buy from our online store. Simply add it to your order from the store.



BUMPER FLAP

- Install Cargo liner
- Attach the Bumper Flap to the loop fastener strip located at the base of the Cargo liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the liftgate.

