

## LAND ROVER RANGE ROVER EVOQUE 2012 to 2019

Our ref: H0531

Packing requirements

CARGO LINER

- No Fittings Required

LIFTGATE COVER

- Minimum of 15 self-adhesive loop fastener tabs



**PLEASE NOTE** – this is a photo of the Rear Plus Cargo Liner with Seat Split version prepared for Bumper Flap

### PREPARATION

- Remove the retractable cargo cover. It can be replaced later.
- Unfold the Hatchbag and place in the vehicle so that the base fits snugly in position. The panel with the Hatchbag label sits against the back of the rear seat.

*Please note: some of these photos are not specific to your vehicle*

### INSTALLING THE BASE

- Position the base snugly into place. Start at the liftgate end.
- The hook fasteners attach directly to the carpet.



### INSTALLING THE FRONT

- Hook & loop fastener straps align to headrests.
- Pass around each post and fasten back onto themselves.
- The hook fastener attaches directly to the carpet.



### NOTE: REAR PLUS VERSIONS

- **YOU MUST UNFASTEN THE HOOK & LOOP FASTENER AND THE HEADREST STRAPS BEFORE YOU RECLINE THE UPPER PARTS OF THE REAR SEATS** (*Please refer to REAR PLUS options on website to see detailed photos*)

## INSTALLING THE SIDES

- Carefully position the side panels snugly into place.
- The hook fastener on the back of the side panel attaches directly to the carpeted panels of the cargo area.



## LAND ROVER ACCESSORIES

- Please note the Cargo Liner will NOT accommodate the "Load Retention System" or the "Social Seating"

## Optional extras

### FREQUENT USE INSTALLATION KIT

If you intend to frequently remove/install the cargo liner from/to your vehicle please note that the carpet will "fluff" up. We offer an alternative Frequent Use Installation Kit. Simply add it to your order from our online store.



*Please note this photo is not specific to your vehicle*

### LIFTGATE COVER

- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



### VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive loop fastener to attach the cargo liner to the plastic / metal trim (Not the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many detailing products. It is highly likely there will be a build-up of silicone. Before applying any loop fastener pads, the surface MUST be thoroughly cleaned using a silicone remover. (The hook & loop fastener cannot be used once it has been in contact with silicone).

We recommend Intensive Tar Remover made by AutoGlym. Wipe off thoroughly any residue with a separate clean dry cloth.

NOTE: the adhesive takes 24hrs to reach full adhesion – do not disturb during.



*Please note the following photos are not specific to your vehicle*

## BUMPER FLAP

- Install Cargo liner
- Attach the Bumper Flap to the loop fastener strip located at the base of the cargo liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the liftgate.

