

MINI COUNTRYMAN 2011-2016

Our Ref: H0532 RAISED

REAR SEATS ARE UPRIGHT, AND SLID AS FAR BACK TO THE LIFTGATE

Adjust the seat back to a relatively upright position.
(Please note: The most upright position was not chosen as it inclines forward, making it uncomfortable for passengers to sit on!)



PACKING REQUIREMENTS

- CARGO LINER
Minimum of 2 self-adhesive loop fastener tabs
750 mm of 20 mm wide self-adhesive loop fastener.
22 of REF: 113
- LIFTGATE COVER
Minimum of 16 self-adhesive loop fastener tabs



REF: 113

VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive loop fastener to attach the cargo liner to the plastic / metal trim (**Not** the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many detailing products. It is **highly likely there will be a build-up of silicone**. Before applying any loop fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The loop fastener cannot be used once it has been in contact with silicone). We recommend Intensive Tar Remover made by AutoGlym. Wipe off thoroughly **any residue with a separate clean dry cloth**.



Unfortunately we are unable to supply this product, as it cannot be transported via our postal carrier.

NOTE: the adhesive takes 24hrs to reach full adhesion – do not disturb during.

FREQUENT USE HOOK & LOOP FASTENER PATCHES – REF: 113

- If you frequently remove/install your Cargo liner from/to your vehicle please note that the carpet will “fluff” up
- We have included a set of Frequent Use hook & loop fastener Patches
- Whilst installing the Cargo liner “sandwich” a Patch between the carpet and the Cargo liner at each fastener location.
- Leave the patch attached to the carpet at all times.



PREPARATION

- Remove the cargo cover. It may be replaced later.
- Unfold the Hatchbag and place in the vehicle. The panel with the Hatchbag label sits against the back of the rear seat.

Please note: not all of the photographs are specific to your vehicle

INSTALLING THE BASE

- Ensure the False Floor is in place
- Position the base snugly into place.
- Attach the four ties to the appropriate tie down hooks. DO NOT over-tighten as this will cause the base of the liner to lift from the floor of the cargo area.



INSTALLING THE FRONT

- Hook & loop fastener straps align to headrests.
- Pass around each post and fasten back onto themselves.
- Any hook fastener on the back side of the liner attaches directly to the carpet panels.



REAR PLUS VERSIONS

- **YOU MUST UNFASTEN THE HOOK & LOOP FASTENER AND THE HEADREST STRAPS BEFORE YOU RECLINE THE UPPER PARTS OF THE REAR SEATS (Please refer to REAR PLUS options on website to see detailed photo's)**



Attach the self-adhesive loop fastener to the plastic



Fasten directly to carpet

INSTALLING THE SIDES

- Carefully position the side panels snugly into place.
- The hook fastener on the back side of the liner attaches directly to the carpet panels.
- Use the pre-cut loop fastener tabs to attach the front of the side panels to the plastic trim.

Strips of self-adhesive loop fastener to the plastic



INSTALLING THE BACK

- Carefully position the back panel snugly into place.
- Cut and attach appropriate lengths of the “uncut” loop fastener to the plastic area as illustrated in this photo above.
- Use the pre-cut loop fastener tabs to attach the rest of the side panels to the plastic trim.

Please note: the following photos are not specific to your vehicle

LIFTGATE COVER

- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



LIFTGATE COVER

BUMPER FLAP

- Install Cargo liner
- Attach the Bumper Flap to the loop fastener strip located at the base of the Cargo liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the liftgate.



BUMPER FLAP