

AUDI Q3 2015 to 2018 RAISED - NO NET / WITH NET

Our ref: *HO542RAISED*

Packing requirements

- CARGO LINER
Requires NO additional fixings
- LIFTGATE COVER
Minimum of 19 self-adhesive loop fastener tabs



Rear Plus (With Seat Split) prepared for a Bumper Flap

VERY IMPORTANT PREPARATION



To ensure a good bond, when using the self-adhesive fastener to attach the cargo liner to the plastic / metal trim (Not the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many valeting products. It is highly likely there will be a build-up of silicone. Before applying any self-adhesive fastener pads, the surface **MUST** be thoroughly cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone). We recommend Intensive Tar Remover made by AutoGlym. Wipe off thoroughly any residue with a separate clean dry cloth.

Unfortunately, we are unable to supply this product, as it cannot be transported via our postal carrier.

NOTE: the adhesive takes 24hrs to reach full adhesion – do not disturb during.

PREPARATION

- Remove the cargo cover. It may be replaced later.
- Ensure the **Luggage Compartment Floor** (REF: "3GD") is **CARPET SIDE UP**
- Unfold the Hatchbag and place in the vehicle so that the base fits snugly in position. The panel with the Hatchbag label sits against the back of the rear seat.

Please note not all the photographs are specific to your vehicle.

INSTALLING THE BASE

- Position the base snugly into place. Start behind the back of the rear seats.
- The hook fastener on the back side of the liner will attach directly to the carpet panels.



INSTALLING THE FRONT

- Hook & Loop fastener straps align to headrests.
- Pass around each post and fasten back onto themselves.
- The hook fastener on the back side of the liner will attach directly to the carpet panels.



REAR PLUS VERSIONS

- **YOU MUST UNFASTEN THE HOK & LOOP FASTENER + THE HEADREST STRAPS BEFORE YOU RECLINE THE UPPER PARTS OF THE REAR SEATS** (*Please refer to REAR PLUS options on website to see detailed photo*)

INSTALLING THE SIDES

- Carefully position the side panels snugly into place.
- The hook fastener on the back side of the liner will attach directly to the carpet panels.



Optional extras

FREQUENT USE INSTALLATION KIT

If you frequently remove/install your Cargo Liner from/to your vehicle, please note that the carpet will “fluff” up – We offer an alternative Frequent Use Installation Kit.

The Frequent Use Installation Kit is available from our online store. Simply add it to your order from the store.



LIFTGATE COVER

- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.

Please note: the following photos are not specific to your vehicle.



BUMPER FLAP

- Install Cargo Liner
- Attach the Bumper Flap to the loop fastener strip located at the base of the Cargo Liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the liftgate.



CARGO LINER EXTENSION

The Cargo Liner Extension provides superior protection to the rear seats when purchased with a **REAR PLUS** option.

- The Cargo Liner Extension is designed to attach to a Rear Plus version liner.
- It offers additional protection to the back of the front seats and the extended cargo area when the rear seats are folded flat. The max width is 148cm (see photo on left). It does not offer full protection to the rear doors.

