

## HONDA CR-V 2013-2016

Our ref: H0549

### INSTALLATION KIT CONTENTS:

- ☐ CARGO LINER  
2500mm cut length of 30mm wide loop fastener.  
Minimum of 8 self-adhesive loop fastener tabs
- ☐ LIFTGATE COVER  
Minimum of 19 self-adhesive loop fastener tabs



Photo shows a Rear Plus WITH Seat Split version

### PREPARATION

- Remove the retractable cargo cover; it may be replaced later.
- Unfold the Hatchbag and place in the vehicle so that the base fits snugly in position. The panel with the Hatchbag label sits against the back of the rear seat.

### VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fastener to attach the cargo liner to the plastic / metal trim (**Not** the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many detailing products. It is **highly likely there will be a build-up of silicone**. Before applying any self-adhesive fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone). We recommend Intensive Tar Remover made by AutoGlym. Wipe off thoroughly **any residue with a separate clean dry cloth**.

Unfortunately, we are unable to supply this product, as it cannot be transported via our postal carrier.

NOTE: the adhesive takes 24hrs to reach full adhesion, do not disturb during.



### INSTALLING

#### BASE

- Position the base of the liner snugly into place.
- Hook fasteners attach directly to the carpet.



## FRONT

- Hook & loop fastener straps align to headrests.
- Pass around each post and fasten close back onto themselves.

## REAR PLUS VERSIONS

- **YOU MUST UNFASTEN THE HOOK & LOOP FASTENER AND THE HEADREST STRAPS BEFORE YOU FOLD THE UPPER PARTS OF THE REAR SEATS.** Please refer to REAR PLUS options on website to see detailed photos.

### “Easy fold-down” rear seatback.

The handles in the cargo area are **covered** by the liner.

Only a **gentle pull** on these handles is required to operate the auto-folding. You can access the handles, (once you have unfastened the headrest straps) by peeling the rear corners away from the fastener, but they **will not be exposed for your dog's roving paws!!!!**



## SIDES

- Carefully position the side panels snugly into place. Use both the small tabs and long length of the self-adhesive loop fasteners to attach the side to the plastic trim.



## REAR

- Carefully position the back panel snugly into place. Use the remaining length of self-adhesive loop fastener to attach the back to the plastic trim.
- Pull back the rubber seal so that you can attach the full width of the fastener. You will need to snip the fastener strip to get it to lie flat.
- The bound edge of the liner can be tucked under the rubber seal when fastening to the hook fastener.



*Please note: Photos are not specific to your vehicle.*

## OPTIONAL EXTRAS

### LIFTGATE COVER

- Line up the Liftgate Cover with the liftgate and clean the areas where the self-adhesive loop fastener tabs will be stuck. (Image 1)
- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



### BUMPER FLAP

- Install the Cargo liner
- Attach the Bumper Flap to the loop fastener strip located at the base of the Cargo liner. (Image 2)
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the liftgate.



### CARGO LINER EXTENSION

The Cargo Liner Extension provides superior protection for the rear seats when purchased with a REAR PLUS option.

- The Cargo Liner Extension is designed to attach to a Rear Plus / Split version liner.
- It provides additional protection for the back of the front seats and the extended floor area when the rear seats are folded flat.
- The max. width is 148cm.
- It offers no protection to the rear doors.
- Attach the Cargo Liner Extension to the main Cargo liner.

