

Volkswagen e-Golf Hatch 2016-present

Our ref: H0552-E

PACKING REQUIREMENTS

- CARGO LINER
1000mm (1mtr) cut length of self-adhesive
loop fastener
- LIFTGATE COVER
20x self-adhesive loop fastener tabs



VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fasteners to attach the cargo liner to the plastic / metal trim (**Not** the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many detailing products. It is **highly likely there will be a build-up of silicone**. Before applying any hook & loop fasteners pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The hook & loop fasteners cannot be used once it has been in contact with silicone). We recommend Intensive Tar Remover made by AutoGlym. Wipe off thoroughly **any residue with a separate clean dry cloth**.

Unfortunately we are unable to supply this product, as it cannot be transported via our postal carrier.

NOTE: the adhesive takes 24hrs to reach full adhesion – do not disturb during.



PREPARATION

- Ensure you have installed the False Floor to correspond with the Cargo Liner version you have ordered.
- Unfold the Hatchbag and place in the vehicle so that the base fits snugly in position. The panel with the Hatchbag label sits against the back of the rear seat.

Please note: not all of the photographs are specific to your vehicle

BASE

- Position the base snugly into place. Start at the liftgate end.
- The hook fastener welded to the back side of the liner will attach directly to the carpeted panels.

BACK

- Use the self-adhesive loop fasteners to attach the back panel to the liftgate plate.



INSTALLING THE FRONT

- Hook & loop fastener straps align to headrests.
- Pass around each post and fasten back onto themselves.
- The hook fastener on the back side of the liner attach directly to the carpet panels.



REAR PLUS VERSIONS

- **YOU MUST UNFASTEN THE HOOK & LOOP FASTENERS AND THE HEADREST STRAPS BEFORE YOU RECLINE THE UPPER PARTS OF THE REAR SEATS (Please refer to REAR PLUS options on website to see detailed photo)**

SIDES

- Carefully position the side panels snugly into place.
- The hook fasteners on to the back side of the liner attach directly to the carpeted panels.
- Use the self-adhesive loop fastener pads to attach the pocket flaps to the reverse face of the plastic inserts.



OPTIONAL EXTRAS

FREQUENT USE INSTALLATION KIT

If you frequently remove/install your Cargo Liner from/to your vehicle, please note that the carpet will “fluff” up. We have an alternative Frequent Use Installation Kit.

The Frequent Use Installation Kit is available to buy from our online store. Simply add it to your order from the store.



BUMPER FLAP

- Install Cargo liner
- Attach the Bumper Flap to the loop fastener strip located at the base of the Cargo liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the liftgate.



Please note: not all of the photographs are specific to your vehicle

LIFTGATE COVER

- Use the self-adhesive loop fastener tabs to attach the back panel to the liftgate plate.

