

MINI Hardtop (2dr ONLY)

2014-present

Our ref: H0589-FRSD

Height adjustable floor raised

Packing requirements

- CARGO LINER
Minimum of 6 self-adhesive loop fastener tabs
- LIFTGATE COVER
Minimum of 15 self-adhesive loop fastener tabs



Please note: Photo shows a Rear Plus Cargo liner with additional Bumper Flap

VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fasteners to attach the cargo liner to the plastic / metal trim (**Not** the carpet); it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many detailing products. It is **highly likely there will be a build-up of silicone**. Before applying any self-adhesive fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The fasteners cannot be used once they have been in contact with silicone). We recommend Intensive Tar Remover made by AutoGlym. Wipe off thoroughly **any residue with a separate clean dry cloth**.

NOTE: the adhesive takes 24hrs to reach full adhesion – do not disturb during.



PREPARATION

- Please ensure that the Rear seat backs are positioned to suit your order – UPRIGHT or RECLINED

“UPRIGHT”

REAR SEATS ARE MOST UPRIGHT



“RECLINED”

REAR SEATS ARE MOST RECLINED



- Remove the cargo cover. It may be replaced later.
- Unfold the Hatchbag and place in the vehicle. The panel with the Hatchbag label sits against the back of the rear seat.

Please note: not all of the photographs are specific to your vehicle

BASE

- Ensure the False Floor is in place and at its highest level.
- Position the base of the Cargo liner snugly into place.
- The hook fasteners welded to the back side of the base attach directly to the carpet.



FITTING FRONT

- Hook & loop fastener straps align to headrests.
- Pass around each post and fasten back onto themselves.

REAR PLUS VERSIONS

- **YOU MUST UNFASTEN THE HOOK & LOOP FASTENERS AND THE HEADREST STRAPS BEFORE YOU RECLINE THE UPPER PARTS OF THE REAR SEATs**

(Please refer to REAR PLUS options on website to see detailed photos)



SIDES

- Carefully position the side panels snugly into place.
- The hook fasteners on the liner attach directly to the carpeted panels.



BACK

- Carefully position the back panel snugly into place.
- Use the pre-cut loop fastener tabs to attach the back panel to the liftgate plastic trim.



Please note: these photos are not specific to your car.

BUMPER FLAP

- Install Cargo liner
- Attach the Bumper Flap to the loop fastener strip located at the base of the Cargo liner.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the liftgate.



LIFTGATE COVER

- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.

