

MAZDA 2 HATCHBACK - 2020-present

Our ref: Ho601

PACKAGING REQUIREMENTS.

CARGO LINER

- 2 x 530mm 30mm wide selfadhesive loop fastener
- 295mm + 265mm 30mm wide selfadhesive loop fastener

LIFTGATE COVER

- 9 x tabs self-adhesive loop fastener
- 880mm 30mm wide self-adhesive loop fastener





VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fasteners to attach the cover to the plastic trim it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many detailing products. It is **highly likely there will be a build-up of silicone**. Before applying any self-adhesive fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone). We recommend Intensive Tar Remover made by AutoGlym. Wipe off thoroughly any residue with a separate clean dry cloth.

NOTE: the adhesive takes 24hrs to reach full adhesion – do not touch during.





STEP I. PREPARATIONS

 Remove the cargo cover. It may be replaced later. (Image A)



STEP 2. INSTALLING THE BASE

• Place the Cargo liner into the cargo area with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges. (Image B)



STEP 3. INSTALLING THE FRONT

- PLUS / SPLIT VERSION ONLY Fasten the hook & loop fasteners between the side panel and the seat panel. (Image C)
- Starting with the middle headrest, loop the hook & loop fastener straps around both headrest posts.
 (Image D). Make sure to hold the front part of the base in position to avoid pulling the Hatchbag too far up. Repeat the procedure with the left and right headrests.





REAR PLUS VERSIONS

You MUST unfasten the hook & loop fasteners and the headrest straps before you recline the upper parts of the rear seats. (*Please refer to REAR PLUS options on website to see detailed photo*)

STEP 4. INSTALLING THE SIDES

- On the left, attach the 295mm long self-adhesive loop fastener strip on the top edge of the side recess as shown in Image E. Repeat this procedure using the 265mm long fastener strip on the right side.
- Attach the hook fastener on the top edge of the cargo liner to the previously attached loop fasteners.
- Stick the 530mm long self-adhesive loop fastener strip on the ridged plastic panel, running from the liftgate lock all the way up the sides as shown in Image F. Start at the liftgate lock end working upwards (Image G), ensuring to press the fastener strip firmly between the ridges.











OPTIONAL EXTRAS

Please note: the following photos are not specific to your vehicle

STEP 5A. LIFTGATE COVER

- Line up the liftgate cover with the liftgate and clean the areas where the self-adhesive fastener tabs will be stuck. (Image 1)
- Use the self-adhesive loop fastener tabs to attach the cover to the bottom of the plastic trim and use the 88mm long fastener strip to attach the top.



STEP 5B. BUMPER FLAP

- Install Cargo liner
- Attach the Bumper Flap to the loop fastener strip located at the base of the Cargo liner. (Image 2)
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the liftgate.



IMAGE 5

OPTIONAL EXTRAS page 2

Please note the following photos are not specific to your vehicle

STEP 5C. CARGO LINER EXTENSION

The Cargo Liner Extension provides superior protection to the rear seats when purchased with a REAR PLUS option.

- The Cargo Liner Extension is designed to attach to a Rear Plus version liner.
- It provides additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.
- It does not offer full protection to the rear doors.

The Bumper Flap and the Cargo Liner Extension cannot be added at a later date.

