

Audi Q7 - 2015 - present

our ref: H0611-HYPLG

INSTALLATION KIT CONTENTS :

CARGO LINER

- **2 x 500 mm** 30mm wide self-adhesive loop fastener
- **2 x 180 mm** 30mm wide self-adhesive loop fastener

WINDOW SILL FLAPS

- **2 x 400 mm** 30mm wide self-adhesive loop fastener
- **6 x tabs** self-adhesive loop fastener

LIFTGATE COVER

- **19 x tabs** self-adhesive loop fastener



Rear Plus with Seat Split cargo liner prepped for a cargo liner extension and bumper flap.



VERY IMPORTANT PREPARATION



To ensure the self-adhesive hook & loop fastener stick to the plastic trim, you **MUST CLEAN** all grime from the plastic and **REMOVE** all **SILICONE** applied during manufacture and detailing.

To do this please:

1. Use a silicone remover, such as AutoGlym Intensive Tar Remover, and apply generously to the surface you want to adhere to.
2. Using a separate clean, dry cloth, thoroughly dry the surface until the cloth starts to drag. Attach one self-adhesive fastener tab to see if it sticks. (Repeat steps 1 and 2 if necessary.) Extra tabs have been provided.
3. Attach the self-adhesive fasteners and let them fully adhere over the next 24 hours for the best bond.

**The self-adhesive fasteners cannot be used once they have been in contact with silicone. Replacement kits are available on our website.*



STEP 1. PREPERATIONS

Please ensure that the rear seat (2nd row) backs are positioned correctly to suit the liner. The seats should be at a incline parallel to the seam on the car wall (shown below)



SET THE REAR SEAT RECLINE TO BE PARALLEL WITH SHOWN LINE



TOO FAR BACK WILL CREASE THE HATCHBAG.



TOO FAR FORWARD WILL PULL HATCHBAG OF THE SEAT.

STEP 2. INSTALLING THE BASE

- Place the cargo liner into the cargo area with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges. (Image A)



STEP 3. INSTALLING THE FRONT

- PLUS / SPLIT VERSION ONLY** - Fasten the hook & loop fasteners between the side panels and the seat panel. (Image B)
- Starting with the middle headrest, fasten the hook & loop fastener straps around both headrest posts. (Image C). Make sure to hold the front part of the base in position to avoid pulling the cargo liner too far up. Repeat the procedure with the left and right headrests.

REAR PLUS VERSIONS



You **MUST** unfasten the hook & loop fasteners and the headrest straps before you recline the upper part of the rear seats. (Please refer to **REAR PLUS / SPLIT** options on website to see detailed photo.)



STEP 4A. INSTALLING THE SIDES

WITHOUT OPTIONAL SILL FLAPS


- Stick the *180 mm self-adhesive loop fastener* to the bottom edge of the plastic side panels just above the carpeted area (highlighted in blue-Image D & E)
- Attach the hook fastener on the top edge of the cargo liner sides directly onto the carpet (Image D)
- Attach the hook fastener strip sewn along the top edge of the cargo liner to the fastener fixed in place previously (image F)
- *NOTE: should you plan to remove and replace your cargo liner regularly we suggest you use a pack of frequent use tabs on both the nearside and offside where the hook fastener attaches to the carpet. These can be purchased online.*



STEP 4B. INSTALLING THE SIDES

WITH OPTIONAL SILL FLAPS

- Attach the self-adhesive loop fastener strip along the entire length inside of the grill, cutting the *400mm wide strip* to length. (image G - highlighted in orange)
- Attach the top edge of the sill flaps onto this fastener strip and attach the bottom edge of the flap directly onto the top edge of the carpet that lines the side of the cargo area (image H - white arrow). Repeat on opposite side
- Use the *6 x tabs self-adhesive loop fastener* to fasten the remaining hook fasteners to the plastic (Image H - highlighted in orange)
- Next follow the instructions in step in 4A to complete the attachment of the side panels.



STEP 5. INSTALLING THE BACK

- Stick the *2 x 500 mm self-adhesive loop fastener* to the panel located on either side of the lock at the tailgate end of the cargo area. Attach the cargo liner to it using the hook fastener on the liner. (highlighted in yellow - Image I)



OPTIONAL EXTRAS

Please note: not all of the photographs are specific to your vehicle.

STEP 6A. LIFTGATE COVER

- Line up the tailgate cover with the tailgate and clean the areas where the self-adhesive loop fastener tabs will be stuck. (Image 4)
- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



STEP 6B. BUMPER FLAP

- Fit the cargo liner
- Attach the Bumper Flap to the loop fastener strip located at the base of the cargo liner. (Image 5)



The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the tailgate.



STEP 6C. CARGO LINER EXTENSION

The Cargo liner extension provides superior protection for the rear seats when purchased with a REAR PLUS option.

- The Cargoliner extension is designed to attach to a Rear Plus/Split version liner.
- It provides additional protection for the back of the front seats and the extended floor area when the rear seats are folded flat.
- It does not offer full protection to the rear doors
- Attach the Cargoliner extension to the main cargo liner (Image 6)
- Fasten the two ties in the corner together (Orange arrows - Image 7)
- Fasten the hook & loop fastener straps around the headrest posts. (Blue arrows - Image 7)
- Stick one self adhesive tab to the side. Fasten the tab welded on the reverse of the liner to it (Green arrow - Image 8)
- Repeat on opposite side

