

## MINI CLUBMAN - 2016-present

### 4 OPTIONS - (Raised/Low - Upright/reclined)

Our ref: H0612

#### PACKAGING REQUIREMENTS.

CARGO LINER

- **6 x tabs** self-adhesive loop fastener

LIFTGATE COVER

- **26 x tabs** self-adhesive loop fastener



Photo: Raised-Upright Split seat version



Photo: Low-Reclined Split seat version



#### VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive loop fastener to attach the cover to the plastic trim it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many detailing products. It is **highly likely there will be a build-up of silicone**. Before applying any loop fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The hook & loop fastener cannot be used once it has been in contact with silicone). We recommend Intensive Tar Remover made by AutoGlym. Wipe off thoroughly **any residue with a separate clean dry cloth**.

**NOTE:** the adhesive takes 24hrs to reach full adhesion – do not touch during.



## STEP 1. PREPARATIONS

- Remove the cargo cover. It may be replaced later. (Image A)



### RAISED FLOOR + UPRIGHT SEATS

- Please make sure the false floor is inserted (Image B)
- Please incline your seats to the upright position as shown in Image E



### RAISED FLOOR + RECLINED SEATS

- Please make sure the false floor is inserted (Image B)
- Please recline your seats to the reclined position as shown in Image D



### LOWERED FLOOR + UPRIGHT SEATS

- Please remove and store the false floor (Image C). It cannot be replaced later.
- Please incline your seats to the upright position as shown in Image E



### LOWERED FLOOR + RECLINED SEATS

- Please remove and store the false floor (Image C). It cannot be replaced later.
- Please recline your seats to the reclined position as shown in Image D



## STEP 2. INSTALLING THE BASE

- Place the Cargo liner into the cargo liner with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges. (Image F)



### LOWERED FLOOR OPTION ONLY

- Push the lowered floor section of the Cargo liner into the lowered floor compartment of the cargo area and push it snugly into the corners. (Image G)



### STEP 3. INSTALLING THE FRONT

- - **PLUS / SPLIT VERSION ONLY** - Fasten the hook & loop fastener between the side panel and the seat panel. (Image H)
- Starting with the middle headrest loop the hook & loop fastener straps around both headrest posts. (Image I). Make sure to hold the front part of the base in position to avoid pulling the Hatchbag too far up. Repeat the procedure with the left and right seat.

#### REAR PLUS VERSIONS

You **MUST** unfasten the hook & loop fastener and the headrest straps before you recline the upper parts of the rear seats. (Please refer to **REAR PLUS** options on website to see detailed photo)



### STEP 4. INSTALLING THE SIDES

- Position the sides of the Cargo liner into place. Firmly press the sides to securely fasten the hook fastener to the carpet. (Image J)
- Attach the Cargo liner flap on the top edge of the cargo liner on the carpeted ledge on both sides of the cargo area. Firmly press to securely fasten the hook fastener to the carpet. (Image K)
- Attach the cargo liner to the rear plastic lip using the self-adhesive loop fastener provided by lining up the hook fastener on the Cargo liner to the correct position. These areas are shown in Image L & Image M



#### RECLINED OPTION ONLY

- Tie the 2 straps located at the front of the sides around the metal loop on the recline mechanism. (Image N)



Photo: Low-Reclined Split seat version

## OPTIONAL EXTRAS

*Please note the following photos are not specific to your vehicle*

### STEP 5A. LIFTGATE COVER

- Line up the liftgate cover with the liftgate and clean the areas where the self-adhesive loop fastener tabs will be stuck. (Image 1)
- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.

### STEP 5B. BUMPER FLAP

- Install Cargo liner
- Close the door on the left side and open the door on the right.
- Attach the smaller section of the bumper flap to the loop fastener on the base of the Cargo liner; ensure the inner edge of the flap aligns to the door on the left (arrow in Image 2)
- Open the door on the left and install the larger section: it is designed to overlap the smaller section.
- The nearside section can remain folded into the vehicle when just the door on the right is open. Both flaps can be detached and stored elsewhere when you close the liftgate doors.



## OPTIONAL EXTRAS page 2

*Please note the following photos are not specific to your vehicle*

### STEP 5C. CARGO LINER EXTENSION

The Cargo Liner Extension provides superior protection to the rear seats when purchased with a REAR PLUS option.

- The Cargo Liner Extension is designed to attach to a Rear Plus version liner.
- It provides additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.
- It does not offer full protection to the rear doors

#### **IMPORTANT NOTE:**

*The Bumper Flap & the Cargo Liner Extension cannot be added at a later date.*



### STEP 5D. FREQUENT USE INSTALLATION KIT

- If you frequently remove/install your Cargo liner from/to your vehicle, please note that the carpet will “fluff” up. We offer an alternative Frequent Use Installation Kit.

The Frequent Use Installation Kit is available to buy from our online store. Simply add it to your order from the store. The kits can also be ordered at a later date.

