

AUDI A4 (INC. Allroad & S4) - 2017 to present

Our ref: H0613-SH1/SH2/SH3/SH4/SH5/SH6

PACKAGING REQUIREMENTS.

CARGO LINER

- none

LIFTGATE COVER

- 16 x tabs self-adhesive loop fasteners



VERY IMPORTANT PREPARATION



To ensure the self-adhesive hook & loop fasteners stick to the plastic trim, you **MUST CLEAN** all grime from the plastic and **REMOVE** all **SILICONE** applied during manufacture and detailing.

To do this, please:

1. Use a silicone remover, such as AutoGlym Intensive Tar Remover, and apply generously to the surface you want to adhere to.
2. Using a separate clean, dry cloth, thoroughly dry the surface until the cloth starts to drag. Attach one self-adhesive fastener tab to see if it sticks. (Repeat steps 1 and 2 if necessary.) Extra tabs have been provided.

Attach the self-adhesive fasteners and let them fully adhere over the next 24 hours for the best bond.

*The self-adhesive fasteners cannot be used once they have been in contact with silicone. Replacement kits are available on our website.



STEP I. PREPARATIONS

- Please remove the cargo cover and the net cassette (Image A). They may be replaced later.
- If you have ordered Shape 2 / 4 / 6 please lower the offside Net across the recess



Please note not all of the photographs are specific to your vehicle

STEP 2. FITTING BASE

- Place the Cargo liner into the cargo area with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges.



STEP 3. FITTING THE FRONT

- **PLUS / SPLIT VERSION ONLY** - Fasten the hook & loop fasteners between the side panels and the seat panel. (Image C)
- Starting with the middle headrest, loop the hook & loop fastener straps around both headrest posts. (Image D). Make sure to hold the front part of the base in position to avoid pulling the Cargo liner too far up. Repeat the procedure with the left and right headrests.



REAR PLUS VERSIONS

You **MUST** unfasten the hook & loop fasteners and the headrest straps before you recline the upper parts of the rear seats. (Please refer to **REAR PLUS** options on website to see detailed photo)

STEP 4. FITTING THE SIDES

- SHAPE 2/4/6 ONLY**—Lower the net on the right side recess of the cargo area and push in the cargo liner pocket. Push the well firmly to the floor so the fastener on the well secures to the recess base. (Image E)
- Attach the sides of the cargo liner to the top edge of the carpeted area of the cargo sides. (Image F).



OPTIONAL EXTRAS

Please note: the following photos are not specific to your vehicle

STEP 5A. LIFTGATE COVER



Line up the liftgate cover with the liftgate and clean the areas where the self-adhesive fastener tabs will be stuck. **(Image 1)**

- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



STEP 5B. BUMPER FLAP

- Install Cargo Liner
- Attach the Bumper Flap to the loop fastener strip located at the base of the Cargo Liner. **(Image 2)**
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the liftgate.



OPTIONAL EXTRAS page 2

Please note the following photos are non-specific to your vehicle

STEP 5C. CARGO LINER EXTENSION

The Cargo Liner Extension provides superior protection to the rear seats when purchased in conjunction with a REAR PLUS option. (Image 3)

- The Cargo Liner Extension is designed to attach to a Rear Plus version liner.
- It provides additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.
- It does not offer full protection to the rear doors

The Bumper Flap (5A) and Cargo Liner Extension (5C) cannot be added at a late date



STEP 5D. FREQUENT USE INSTALLATION KIT

- If you frequently remove/fit your Cargo Liner from/to your vehicle please note that the carpet will “fluff” up – We offer an alternative Frequent Use Installation Kit. (Image 4+5)

The Frequent Use Installation Kit is available to buy from our online store. Simply add it to your order from the store.

