

Installation Instructions hatchbag.us

MAZDA CX-3 - 2016-present

FLOOR LOW + MID + RAISED Our ref: H0631-FRSD+FMID+FLOW

PACKAGING REQUIREMENTS.

CARGO LINER

- 2x 230mm 30mm wide selfadhesive loop fastener
- 2x 155mm 30mm wide selfadhesive loop fastener
- 2x 670mm 30mm wide selfadhesive loop fastener
- 1x SA loop fastener tab
- LIFTGATE COVER
- 22 x tabs self-adhesive loop fastener



IMAGE SHOWS THE RAISED FLOOR VERSION - SPLIT CARGO LINER PREPARED FOR BUMPER FLAP -



VERY IMPORTANT PREPARATION

To ensure a good bond, when using the self-adhesive hook & loop fasteners to attach the cover to the plastic trim it is most important to remove silicone film from the vehicle trim. Silicone is applied during manufacture and can also be found in many detailing products. It is **highly likely there will be a build-up of silicone**. Before applying any self-adhesive fastener pads, the surface **MUST be thoroughly** cleaned using a silicone remover. (The fasteners cannot be used once it has been in contact with silicone). We recommend Intensive Tar Remover made by AutoGlym. Wipe off thoroughly **any residue with a separate clean dry cloth**.

NOTE: the adhesive takes 24hrs to reach full adhesion – do not touch during.



STEP I. PREPARATIONS

- Remove the cargo cover. It may be replaced later.
- Please insert / remove the false floor in order to match your order.

STEP 2. INSTALLING THE BASE

• Place the cargo liner into the cargo area with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges. The hook fasteners on the back side attach directly to the carpet. (Image A)

STEP 3. INSTALLING THE FRONT

- - PLUS / SPLIT VERSION ONLY Fasten the hook & loop fasteners between the side panels and seat panel. (Image B)
- Starting with the middle headrest, loop the hook & loop fastener straps around both headrest posts. (Image C). Make sure to hold the front part of the base in position to avoid pulling the Hatchbag too far up. Repeat the procedure with the left and right headrests.

REAR PLUS VERSIONS

You MUST unfasten the hook & loop fasteners and the headrest straps before you recline the upper parts of the rear seats. (*Please refer to REAR PLUS / SPLIT options on website to see detailed photo*)







STEP 4. INSTALLING THE SIDES

- Attach the 155mm long loop fastener strips onto the top-front and 230mm loop fastener strips to the top-back of the plastic sides as shown in Image D. Do this for both sides of the cargo area.
- Attach the 670mm long self-adhesive loop fastener strips along the ridged panel at the liftgate opening, up to the sides of the cargo area. (Image E) Snip into the fastener strip to help if follow the corners.
- Stick one self-adhesive loop fastener tab to inside center of the back panel as shown by the arrow in Image F.
- Attach the liner to this fastener (Image F)



OPTIONAL EXTRAS

Please note the following photos are not specific to your vehicle

STEP 5A. LIFTGATE COVER

- Line up the liftgate cover with the liftgate and clean the areas where the self-adhesive fastener tabs will be stuck. (Image 1)
- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.

STEP 5B. BUMPER FLAP

- Install Cargo liner
- Attach the Bumper Flap to the loop fastener strip located at the base of the Cargo liner.
- The Bumper Flap is one standard length for all models. Trim the length to suit your requirements. Ensure you do not cut through the stitching.
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the liftgate.





OPTIONAL EXTRAS page 2

Please note: the following photos are not specific to your vehicle

STEP 5C. CARGO LINER EXTENSION

The Cargo Liner Extension provides superior protection to the rear seats when purchased with a REAR PLUS option.

- The Cargo Liner Extension is designed to attach to a Rear Plus version liner.
- It provides additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.
- It does not offer full protection to the rear doors.

The Bumper Flap and the Cargo Liner Extension cannot be added at a later date.

