

MINI COUNTRYMAN - 2017 - 2024

OUR REF: H0656-HYNO

INSTALLATION KIT CONTENTS:

☐ CARGO LINER

- **2x 400 mm** 30mm wide self-adhesive loop fastener

☐ LIFTGATE COVER

- **22 x tabs** self-adhesive loop fastener



FRSD
NET Split Cargo liner
prepared for Bumper Flap

FOUT
NONET Split Cargo liner
prepared for Bumper Flap



VERY IMPORTANT PREPARATION



To ensure the self-adhesive hook & loop fastener sticks to the plastic trim, you **MUST CLEAN** all grime from the plastic and **REMOVE** all **SILICONE** applied during manufacture and detailing.

To do this please:

1. Use a silicone remover, such as AutoGlym Intensive Tar Remover and apply generously to the surface you want to adhere to.
2. Using a separate clean & dry cloth, thoroughly dry the surface until the cloth starts to drag. Attach one self-adhesive fastener tab to see if it sticks. (Repeat steps 1 to 2 if necessary)
3. Attach the fasteners and let them fully adhere over the next 24 hours for the best bond.



**The fasteners cannot be used once they have been in contact with silicone. Replacement kits are available on our website.*

STEP 1. PREPARATIONS

- Remove the cargo cover. It may be replaced later.
- Set your 2nd-row seat rake to the most reclined position. (Image A)
- Slide the 2nd-row as far back to the liftgate as possible.

Note! If you order the FRSD (floor raised) the liner will not provide access to the underfloor storage! The liner must be undone and pushed towards the front to gain access, and re installed after. (Image B)



STEP 2. INSTALLING THE BASE

- Place the Cargo liner into the cargo area with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges. The hook fasteners on the back side of the liner attach directly to the carpet. (Image C)



STEP 3. INSTALLING THE FRONT

- - **PLUS / SPLIT VERSION ONLY** - Fasten the hook & loop fasteners between the side panels and the seat panel. (Image D)
- Starting with the middle headrest, loop the hook & loop fastener straps around both headrest posts. (Image E). Make sure to hold the front part of the base in position to avoid pulling the Hatchbag too far up. Repeat the procedure with the left and right headrests.



REAR PLUS VERSIONS

You **MUST** unfasten the hook & loop fasteners and the headrest straps before you recline the upper parts of the rear seats. (Please refer to **REAR PLUS / SPLIT** options on website to see detailed photo)

STEP 4. INSTALLING THE SIDES & BACK

- **- NET VERSION ONLY** - Push the near side of the Cargo liner over the net on the recess on the left side of the cargo area, and align the slot with the net edges. **(Image F)**
- Attach the hook fasteners on the top and back edge of the sides of the Cargo area directly on the top edge of the carpeted sides of the cargo area. **(Image F)**
- Stick the 30mm wide self-adhesive loop fastener strips onto the plastic panel located on either side of the lock at the liftgate end of the cargo area. Fasten the Cargo liner to it using the hook fasteners on the liner. **(Image G)**



OPTIONAL EXTRAS

Please note the following photos are not specific to your vehicle

STEP 5A. LIFTGATE COVER

- Line up the liftgate cover with the liftgate and clean the areas where the self-adhesive fasteners tabs will be stuck. (Image 1)
- Use the self-adhesive loop fasteners tabs to attach the cover to the plastic trim.



STEP 5B. BUMPER FLAP

- Install Cargo liner
- Attach the Bumper Flap to the loop fastener strip located at the base of the Cargo liner. (Image 2)
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the liftgate.



OPTIONAL EXTRAS page 2

Please note the following photos are non-specific to your vehicle

STEP 5C. CARGO LINER EXTENSION

The Cargo Liner Extension provides superior protection for the rear seats when purchased with a REAR PLUS option.

- The Cargo Liner Extension is designed to attach to a Rear Plus / Split version liner.
- It provides additional protection for the back of the front seats and the extended floor area when the rear seats are folded flat.
- It does not offer full protection for the rear doors.
- Attach the Cargo Liner Extension to the main Cargo liner. (Image 3)
- Fasten the two ties in the corner together. (Orange arrows - Image 4)
- Fasten the hook & loop fastener straps around both headrest posts. (Blue arrows - image 4)
- Attach the hook fastener tab welded on the back corner of the cargo liner extension to the carpet on the cargo side (Green arrow - image 8)
- Repeat on opposite side

The Bumper Flap and the Cargo Liner Extension cannot be added at a later date.

STEP 5D. FREQUENT USE INSTALLATION KIT

- If you frequently remove/install your Cargo liner from/to your vehicle, please note that the carpet will “fluff” up. We offer an alternative Frequent Use Installation Kit. (Image 4 & 5)

The Frequent Use Installation Kit is available to buy from our store. Simply add it to your order from the store. The kit can also be ordered at a later date.

