

Jeep Compass - 2017-present

False floor raised & lowered (No speaker on the right)

our ref: H0740

Packaging requirements:

☐ CARGO LINER

- 2 x 260 mm 30mm wide self-adhesive loop fastener
- 2 x 190 mm 30mm wide self-adhesive loop fastener
- 23 x tabs self-adhesive loop fastener

☐ LIFTGATE COVER

- 23 x tabs self-adhesive loop fastener



Left: Cargo liner with rear split for the false floor lowered

Right: Cargo liner with rear split for the false floor raised



VERY IMPORTANT PREPARATION



To ensure the self-adhesive hook & loop fastener stick to the plastic trim, you **MUST CLEAN** all grime from the plastic and **REMOVE** all **SILICONE** applied during manufacture and detailing.

To do this please:

1. Use a silicone remover, such as AutoGlym Intensive Tar Remover and apply generously to the surface you want to adhere to.
2. Using a separate clean & dry cloth, thoroughly dry the surface until the cloth starts to drag. Attach 1 self-adhesive fastener tab to see if it sticks. (Repeat step 1 to 2 if necessary) A couple of spares have been provided.
3. Attach the self-adhesive fasteners and let them fully adhere over the next 24 hours for the best bond.

**The self-adhesive fasteners cannot be used once they have been in contact with silicone. Replacement kits are available on our website.*



STEP 1. PREPARATIONS

- Remove the cargo cover.
- Set the floor level to fit the specification of your order.

STEP 2. INSTALLING THE BASE

- Place the cargo liner into the cargo area with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges. The hook fasteners on the back side attach directly to the carpet. (Image A)
- Attach one self-adhesive loop fastener tab in the plastic pockets in the recesses of both sides of the cargo area. Align these to the hook fastener on the base of the liner. (Image B)



STEP 3. INSTALLING THE FRONT

- - PLUS / SPLIT VERSION ONLY - Fasten the hook & loop fasteners between the side panels and the seat panel. (Image C)
- Starting with the middle headrest, fasten the hook & loop fastener straps around both headrest posts. (Image D). Make sure to hold the front part of the base in position to avoid pulling the cargo liner too far up. Repeat the procedure with the left and right headrests.

REAR PLUS VERSIONS

- You MUST unfasten the hook & loop fasteners and the headrest straps before you recline the upper parts of the rear seats. (Please refer to REAR PLUS / SPLIT options on website to see detailed photo)



STEP 4. INSTALLING THE SIDES & BACK

- Hang the sides of the cargo liner up using the hook in the sides and the corresponding hole in the cargo liner. (white arrow - Image E) Push the cargo liner pockets into the plastic pockets in the cargo recesses.



Attach the 2 self-adhesive loop fastener strips (highlighted in blue) on each side of the cargo area aligned with the hook fastener on the liner. (Image F)



Attach 6 self adhesive tabs (highlighted in green) onto each side of the cargo area aligned with the hook fasteners on the liner. (image F & G)



INSTALLING THE SIDES & BACK

- Attach 4 self adhesive tabs (highlighted in pink) to the ridged back panel on either side of the liftgate lock aligned with the hook fasteners on the back side of the liner. (Image H)

FLOW - FALSE FLOOR LOWERED VERSION ONLY

- Fasten one self adhesive tabs onto the center of the rear panel (orange arrow) aligned with the hook fastener on the back side of the liner. (Image H)



OPTIONAL EXTRAS

Please note: the following photos are not specific to your vehicle

STEP 5A. LIFTGATE COVER

- Line up the liftgate cover with the liftgate and clean the areas where the self-adhesive loop fastener tabs will be stuck. (Image 3)
- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.



STEP 5B. BUMPER FLAP

- Install Cargo Liner
- Attach the Bumper Flap to the loop fastener strip that located at the base of the liner. (Image 4)
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the liftgate.



OPTIONAL EXTRAS page 2

Please note: the following photos are not specific to your vehicle

STEP 5D. CARGO LINER EXTENSION

The Cargo Liner Extension provides superior protection to the rear seats when purchased with a REAR PLUS option. (Image 3 & 4)

- The Cargo Liner Extension is designed to attach to a Rear Plus/Split version liner.
- It provides additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.
- It does not offer full protection to the rear doors.
- Attach the floor extension to the main cargo liner. (Image 3)
- Fasten the two ties in the corner together (Orange arrows - Image 4)
- Fasten the hook & loop fastener straps around both headrest posts. (Blue arrows - Image 4)



The Bumper Flap and the Cargo Liner Extension cannot be added at a late date.

STEP 5E. FREQUENT USE INSTALLATION KIT

- If you frequently remove/install your cargo liner from/to your vehicle, please note that the carpet will “fluff” up – we offer an alternative Frequent Use Installation Kit. (Image 5 & 6)

The Frequent Use Kit is available to buy from our online store. Simply add it to your order from the store. The kits can also be ordered at a later date.

