

Audi A6 allroad/RS6 Avant – 2020/2021 – Present

our ref: H0754

INSTALLATION KIT CONTENTS:

CARGO LINER

- 4 x ref: 121
- 2 x 430 mm 20mm wide self-adhesive loop fastener
- 2 x 400 mm 30mm wide self-adhesive loop fastener

LIFTGATE COVER

- 22 x tabs self-adhesive loop fastener



Rear Plus with seat split cargo liner prepped for a Bumper flap and Cargo liner Extension



REF:121



VERY IMPORTANT PREPARATION



To ensure the self-adhesive hook & loop fastener stick to the plastic trim, you **MUST CLEAN** the plastic from grime and **REMOVE** all the **SILICONE** applied during manufacture and detailing.

To do this please:

1. Use a silicone remover, such as 'Auto-Glym Intensive Tar Remover' and apply generously to the surface you want to adhere to.
2. Using a separate clean & dry cloth, thoroughly dry the surface until the cloth starts to drag. Attach 1 self-adhesive fastener tab to see if it sticks. (Repeat step 1 to 2 if necessary) A couple of spares have been provided.
3. Attach the self-adhesive fasteners and let them fully adhere over the next 24 hours for the best bond.

**The self-adhesive fasteners cannot be used once it has been in contact with silicone. Replacement kits are available from our website.*



STEP 1. PREPARATIONS

- Remove the cargo cover. It may be replaced later.
- Lower the nearside net. (image A)



STEP 2. INSTALLING BASE

- Fold the rear seats flat prior to placing the cargo liner into the cargo area.
- Place the cargo liner into the cargo area with the Hatchbag logo at the seat end. Flatten the base so it fits snugly against the edges. (image B)
- Push the foam tabs sewn onto the front end of the base into the slot between the base and the rear seats. (Image C)



STEP 3. INSTALLING THE SIDE BUNGEEES

- Pass the loop end of the elastic bungee over the hook located in the centre of the cargo area sides (Image D)
- Pass the hook end of the elastic bungee over the rear seat locking "D"Ring (Image E)
- Fold the seats back up trapping the hooks.



STEP 4. INSTALLING THE FRONT

- - **PLUS / SPLIT VERSION ONLY** - fasten the hook & loop fasteners between the side panels and the seat panel. (image F)
- Starting with the middle headrest, fasten the hook & loop fastener straps around both headrest posts. (image G). Make sure to hold the front part of the base in position as not to pull the cargo liner too far up. Repeat the procedure with the left and right headrests.

REAR PLUS VERSIONS

- You **MUST** unfasten the hook & loop fasteners + the headrest straps before you recline the rear seat uppers. (*Please refer to REAR PLUS / SPLIT options on website to see detailed photo*)



STEP 5. INSTALLING THE SIDES

- Attach the **430 mm** 20mm wide self-adhesive loop fastener to the bottom edge of the side plastic panels just above the carpeted area. (refer to green highlights - Image H)
- Insert 2 x ref:121 fastener tabs on each side of the Liftgate end of the cargo area. To do this peel back the rubber and slot the plastic end of the fastener tabs behind the cargo area carpeted panel. (Image I)
- Repeat on opposite side.



STEP 6. INSTALLING THE BACK

- Stick the **400 mm** 30mm wide self-adhesive loop fastener onto the chrome panel located at the Liftgate end of the cargo area side and in line with the hook fastener sewn onto the reverse side of the cargo liner. (refer to yellow highlights - image J)
- Repeat on opposite side.



STEP 7. INSTALLING THE SIDES CONT.....

- Place the nearside panel into the recess.(image K)
- * Fasten the top and back edge of the Cargo liner side to the previously attached loop fastener (refer to green highlights - Image H + K)
- * You may need to slide the ref: 121 tabs up or down to align them with the welded hook fastener (refer to orange highlights - Image I + K)
- Push the protruding hook fastener strips under the net on all 3 sides. (refer to arrows Image L)
- Fasten the loop fastener over these tabs and raise the net.(image M)

* Repeat on nearside



OPTIONAL EXTRAS

Please note the following photos are non-specific to your vehicle

STEP 8A. LIFTGATE COVER



Line up the Liftgate Cover with the liftgate and clean the areas where the self-adhesive loop fastener tabs will be stuck. (image 1)

- Use the self-adhesive loop fastener tabs to attach the cover to the plastic trim.

STEP 8B. BUMPER FLAP

- Fit cargo liner
- Attach the Bumper Flap to the loop fastener strip that has been manufactured into the base of the cargo liner. (image 2)
- The Bumper Flap either folds into the vehicle OR can be detached and stored elsewhere when you close the Liftgate.

STEP 8C. CARGO LINER EXTENSION

The 'Cargo Liner Extension' offers superior protection to the rear seats when purchased in conjunction with a REAR PLUS option. (image 3 & 4)

- The Cargo Liner Extension is designed to attach to a Rear Plus/Split version liner.
- It offers additional protection to the back of the front seats and the extended floor area when the rear seats are folded flat.
- It will offer no full protection to the rear doors
- Attach the Cargo Liner Extension to the main cargo liner (Image 3)
- Fasten the two ties in the corner together (Orange arrows - Image 4)
- Fasten the hook & loop fastener straps around both headrest posts. (Blue arrows - Image 4)



The Bumper Flap 7B and the Cargo Liner Extension 7C cannot be added at a late date